



professional **earphones**

atrio

**FUTURE
SONICS** ®
atrio® Professional Earphones
USER MANUAL



INSTRUCTIONS READ ME FIRST

1 Unpack your Atrio® professional earphones and the enclosed materials. They include the medium-sized EarFills™ sleeves attached. Correct fit is essential for best audio quality and comfort so be certain to select the type and size that provide the best seal.

2 To change sleeves, gently slide and rotate the desired fit option onto the nozzle of each earphone until it reaches the flare point just above the base.

Do not force the sleeves onto the earphones.

3 To wear ComfortFit™ foam sleeves, place the mounted sleeve between your thumb and finger; gently, compress the foam evenly on all sides. While compressed, insert the earphone into the ear canal gently and hold it in place until it expands, within 7 seconds.

4 A snug fit and proper coupling to the ear canal wall are essential to achieve best results in the lower frequency range. Be certain to try each fit option included to achieve the best audio quality, comfort and performance from your earphones.

5 Do not force or proceed if the earphone causes discomfort in any way. If discomfort occurs, try the next smaller size sleeve. You will know when the earphones are properly fitted by the significant reduction of external noise.

6 Make sure the volume on your output device is reduced to the lowest setting and insert the headphone plug into the device's headphone jack. Gradually increase volume to a comfortable listening level.

To avoid potential risks and/or harm, do not use your professional earphones for methods, applications and/or devices other than those indicated by the manufacturer.

HEAR WHAT YOU'VE
BEEN MISSING!®

TROUBLESHOOTING

TIPS & HINTS

IF YOU NOTICE . . .

Not enough low bass response

TRY THIS

Try different sleeve sizes for best fit/proper coupling in the ear canal. Be certain the depth into the canal is adequate.

Not staying in place in ear

Try adjusting the position of the universal sleeve on the nozzle by gently rotating it away from the base ($\pm 1/8$ inch) for length and fit.

Difficulty inserting the foam sleeves

Roll the sleeve so that it is evenly compressed on all sides, then insert into the ear canal. Also, try different sleeve sizes as needed.

Audio levels too low

Check your device sensitivity gain and/or the master output level of the source audio.

Only hearing one side

Check to see that connector is completely inserted into the jack and/or check output levels of your device.

Muffled sound, less clarity

Use the loop cleaning tool to check/clear the nozzle opening and/or sleeves with a gentle outward rotating motion to remove debris.

For additional support, contact us directly online at www.FutureSonics.com.

CARE AND MAINTENANCE

CLEAN

Carefully clean earphones by using a soft cloth to wipe the stem of the earpiece.

If necessary, a mild soap and non-alcohol based anti-bacterial solution. Wipe completely dry before use.

PROTECT

Avoid submerging earphones in liquids and avoid moisture.

Store earphones in carrying case when not in use.

MAINTAIN

Replace foam and silicon sleeves regularly for optimal performance and cleanliness.

Additional or replacement sleeves for your Future Sonics Atrio® professional earphones are available direct. Or upgrade to longer-lasting Softerwear™ custom-fit molded sleeves or Ear Monitors® brand custom personal monitors.

Visit us at
www.FutureSonics.com
or call us toll-free at
1.877.FSI.EARS
1.877.374.3277

IMPORTANT WARNING

Extreme volume and/or prolonged exposure from elevated sound pressure levels (SPL) can cause serious and permanent damage to your ears and hearing.

For best results and optimum safety, we recommend that you adjust your earphones to the lowest volume at which you can comfortably hear the audio output.

Always turn volume down before connecting earphones to your amplifier and/or before inserting earphones into your ears. Once earphones are connected and inserted into your ears, gradually increase the volume to a comfortable listening level.

Do not use earphones in environments where a failure to hear surrounding sounds could be dangerous, such as while driving a car, operating machinery or while biking or walking on roadways.

This product includes small parts and cables that may create a choking hazard. Keep away from young children.

Consult regularly with a physician, audiologist or hearing specialist if you have problems hearing, excessive wax build-up or any discomfort after use.

LIMITED WARRANTY

Future Sonics hereby warrants that this product is without defect in materials, workmanship and/or manufacture for a period of one (1) year from the original date of purchase from an authorized dealer, retailer or licensed reseller. This warranty includes housing assembly, casing and original parts.

Future Sonics will, at its option, repair or replace any defective product within the term of this warranty when the original product is returned with its original proof of purchase (required). This warranty does not apply to any product or part thereof damaged through alteration, mishandling, misuse,

neglect or accident. This warranty is in lieu of all other warranties, expressed or implied, and no person or representative is authorized to assume for the company any other liability in connection with the sale of this product. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

CONTACT

H.E.A.R. applauds Future Sonics' new professional earphones as a significant step forward in hearing conservation due to increased clarity across a broad range that measurably reduces the need for excessive amplification.

- Kathy Peck
Director of H.E.A.R.®

For more information, visit hearnet.com.



TM and © 2010 Future Sonics Inc. All rights reserved.

Atrio®, Atrio logo, EarFills™, ComfortFit™, Softerwear™, "believe your ears®", the "FS®" ear icon and the associated images, likenesses, logos and representations are trademarks of Future Sonics Inc.



416 Green Lane • Suite 2
Bristol, Pennsylvania 19007
1.877.FSI.EARS / 1.215.826.8826
www.FutureSonics.com
info@FutureSonics.com

HEAR WHAT YOU'VE BEEN MISSING!

Producing the finest audio quality is our first priority. That is followed by reliability and our outstanding client services. As we continue to improve our products your input makes a difference.

Like you, we're listening.

Of course, audio is subjective, but our Atrio® professional earphones will outperform any comparable products in this category - at any price - and if you are not completely satisfied with the audio quality, return them and we will refund your money.*

We want to hear from you.

Let us know what you think about our Atrio® professional earphones. That's one of the ways we continue to improve our products and we appreciate hearing from you.

To contact us, visit us online at futuresonics.com or call us toll-free at 1.877.FSI.EARS

Thank you for choosing Future Sonics!

*Within 30 days of the date or original purchase. Original proof-of-purchase is required. Subject to terms, condition and limitations. Subject to change without notice.

**FUTURE
SONICS** [®]
atRIO® Professional Earphones





believe your ears®